

**RD-EXP 01**  
**RD-500/600/700 Collection**

# Read Me first

Thank you for downloading "RD-EXP 01: RD-500/600/700 Collection" for the RD-2000.  
This data contains the following number of Sounds.  
67 Tones

## Contents

- 1. RD-EXP01.bin**  
This is the wave expansion data for the RD-2000.
- 2. RD-EXP01multi01\_W.pdf**  
This is the file you're reading.
- 3. RD-EXP01\_Readme\_e.txt**  
This is a text version of the installation instructions.

## Usage

- 1. Copy the downloaded file (RD-EXP01.bin) to the root directory of the USB memory.**
- 2. Plug the USB memory into the MEMORY connector.**
- 3. While pressing the [ENTER] button, turn on the power.**  
The EXP Update Mode will be activated and the screen will display the wave expansion data (e.g. RD-EXP01).
- 4. Use the cursor keys to select the slot into which you want to load the sounds, and press the [ENTER] button.**  
The name of the file on the USB flash drive (RD-EXP01.bin) appears.
- 5. Select the wave expansion data and press the [ENTER] button.**
- 6. When the screen displays "Are you sure?" press the [ENTER] button to load the sounds.**  
If you would like to start over, press the [EXIT] button.  
\* When the RD-2000 is loading the sounds, "Writing.." will be displayed on the screen. It will take approximately five minutes to load the sounds.  
When the RD-2000 is done loading the sounds, "Complete" will be displayed on the screen.
- 7. Reboot the RD-2000.**  
You can see the expansion titles by pressing the [MENU] button and checking SYSTEM-INFORMATION.  
\* If for any reason RD-2000 stops loading the sounds or "Error" is displayed on the screen, please follow the instructions from the beginning.

## Selecting Sounds

- 1. Press the [EXP] button.**
- 2. Point the cursor to the BANK (e.g. S01, 0001), and then select EXP with the Value dial.**

## Copyright

Copyright to this data and the accompanying documentation is the property of Roland Corporation.

## Disclaimers

This sound data is provided as after-sales service for the RD-2000.  
Roland Corporation accepts no responsibility for any damages that may arise from the use of this data.

# はじめにお読みください

このたびは、RD-2000用「RD-EXP 01: RD-500/600/700 Collection」データをダウンロードしていただき、誠にありがとうございます。  
このデータはRD-2000の搭載機能を活かした以下の音色データを収録しています。  
TONE: 67個

## 収録内容

1. RD-EXP01.bin  
RD-2000用のウェーブ・エクスパンション・データです。
2. RD-EXP01multi01\_W.pdf  
このファイルです。
3. RD-EXP01\_Readme\_j.txt  
テキスト版インストール方法です。

## 使用方法

1. ダウンロードしたファイル (RD-EXP01.bin) をUSBメモリーのルート (コンピューター上で見える一番上の階層) にコピーします。
2. USBメモリーをRD-2000本体の背面にあるMEMORY端子に接続します。
3. [ENTER] ボタンを押しながら電源を入れます。  
EXP Update ModeでRD-2000が起動し、SLOT1/2の状態を示す画面が表示されます。
4. 追加したいSLOTをカーソル・キーで選び、[ENTER] ボタンを押します。  
USBメモリー上のファイル名 (RD-EXP01.bin) が表示されます。
5. 追加したいファイル名を選んで、[ENTER] ボタンを押します。
6. 「Are you sure?」が表示されたら、[ENTER] ボタンを押してデータ書き込みを実行します。  
もしやり直したい場合は[EXIT]ボタンを押して、選択しなおしてください。  
※ データ書き込み中は「Writing」の表示が出ています。データ書き込み時間は約5分です。「Complete」と表示が出たら完了です。
7. 電源を入れなおします。  
[MENU] ボタンを押してSYSTEM-INFORMATIONからExpansionのタイトルを確認することができます。  
※ 万が一「Error」が表示されたり途中で中断されたりした場合は、上記の手順1番からやり直してください。

## 音色の選びかた

1. [EXP] ボタンを押します。
2. トーン・ナンバー(S01、0001など)にカーソルを合わせて、バリュー・ダイヤルを回します。

## 著作権について

本データ、添付のドキュメントなどの著作権は、ローランド (株) が保有いたします。

## 免責

本音色データは、RD-2000へのフォローアップ・サービスとして提供するものです。  
本データを使用することによって生ずるいかなる損害についても、ローランド (株) はその責任を負いません。

# Tone List

No.	Name	Program Change
1	500 Grand Pno A1	0
2	500 Grand Pno A2	1
3	500 Grand Pno A3	2
4	500 Grand Pno A4	3
5	500 Grand Pno A5	4
6	500 Grand Pno B1	5
7	500 Grand Pno B2	6
8	500 Grand Pno B3	7
9	500 Grand Pno B4	8
10	500 Grand Pno B5	9
11	500 Grand Pno C1	10
12	500 Grand Pno C2	11
13	500 Grand Pno C3	12
14	500 Grand Pno C4	13
15	500 Grand Pno C5	14
16	500 Grand Pno C6	15
17	500 Grand Pno C7	16
18	500 Grand Pno D1	17
19	500 Grand Pno D2	18
20	500 Grand Pno D3	19
21	600 St.Concert 1	20
22	600 St.Concert 2	21
23	600 St.Concert 3	22
24	600 St.Concert 4	23
25	600 St.Concert 5	24
26	600 St.Concert 6	25
27	600 St.Concert 7	26
28	600 St.Concert 8	27
29	600 St.SemiGrd 1	28
30	600 St.SemiGrd 2	29
31	600 St.SemiGrd 3	30
32	600 St.SemiGrd 4	31
33	600 Euro Piano 1	32
34	600 Euro Piano 2	33
35	600 Euro Piano 3	34
36	600 Euro Piano 4	35
37	600 Full Grand 1	36
38	600 Full Grand 2	37
39	600 Full Grand 3	38
40	600 Full Grand 4	39
41	600 Semi Grand 1	40
42	600 Semi Grand 2	41
43	600 Semi Grand 3	42
44	600 Semi Grand 4	43
45	600 Comp Piano 1	44
46	600 Comp Piano 2	45
47	600 Comp Piano 3	46
48	600 Comp Piano 4	47
49	700 St.Concert 1	48
50	700 St.Concert 2	49
51	700 Dynamic Pno1	50
52	700 Dynamic Pno2	51
53	700 St.Concert 3	52
54	700 BrightPiano1	53
55	700 BrightPiano2	54
56	700 MellowPiano1	55

No.	Name	Program Change
57	700 MellowPiano2	56
58	700 Band Piano 1	57
59	700 Band Piano 2	58
60	700 Honky-Tonk	59
61	700 Rock Piano 1	60
62	700 Rock Piano 2	61
63	700 Soft Piano	62
64	700 Forte Grand1	63
65	700 Forte Grand2	64
66	700 Piano 1	65
67	700 Piano 2	66

## MEMO

Although the sounds of the RD-500/RD-600/RD-700 are faithfully reproduced, the keyboard is more expressive on the RD-2000. If you want to perform with a touch response that is closer to that of the RD-500/RD-600/RD-700, set KEY TOUCH to a lighter setting.

## メモ

RD-500/RD-600/RD-700の音色を忠実に再現しておりますが、RD-2000では鍵盤の表現力が向上しています。RD-500/RD-600/RD-700に、より近いタッチで演奏するには、KEY TOUCHを軽めに設定するとよいでしょう。