

RD-EXP 05

Virtual Tone Wheel Organ Collection

Read Me first

Thank you for downloading “RD-EXP 05: Virtual Tone Wheel Organ Collection” for the RD-2000.

This data contains the following number of Sounds.

31 Tones

Contents

1. RD-EXP 05.bin

This is the wave expansion data for the RD-2000.

2. RD-EXP 05_multi01_W.pdf

This is the file you’re reading.

3. RD-EXP 05_Readme_e.txt

This is a text version of the installation instructions.

Usage

1. Copy the downloaded file (RD-EXP 05.bin) to the root directory of the USB memory.

2. Plug the USB memory into the MEMORY connector.

3. While pressing the [ENTER] button, turn on the power.

The EXP Update Mode will be activated and the screen will display the wave expansion data (e.g. RD-EXP 05).

4. Use the cursor keys to select the slot into which you want to load the sounds, and press the [ENTER] button.

The name of the file on the USB flash drive (RD-EXP 05.bin) appears.

5. Select the wave expansion data and press the [ENTER] button.

6. When the screen displays “Are you sure?” press the [ENTER] button to load the sounds.

If you would like to start over, press the [EXIT] button.

* When the RD-2000 is loading the sounds, “Writing...” will be displayed on the screen. It will take approximately five minutes to load the sounds. When the RD-2000 is done loading the sounds, “Complete” will be displayed on the screen.

7. Reboot the RD-2000.

You can see the expansion titles by pressing the [MENU] button and checking SYSTEM-INFORMATION.

* If for any reason RD-2000 stops loading the sounds or “Error” is displayed on the screen, please follow the instructions from the beginning.

Selecting Sounds

1. Press the [EXP] button.

2. Point the cursor to the BANK (e.g. S01, 0001), and then select EXP with the Value dial.

Copyright

Copyright to this data and the accompanying documentation is the property of Roland Corporation.

Disclaimers

This sound data is provided as after-sales service for the RD-2000.

Roland Corporation accepts no responsibility for any damages that may arise from the use of this data.

はじめにお読みください

このたびは、RD-2000 用「RD-EXP 05:Virtual Tone Wheel Organ Collection」データをダウンロードしていただき、誠にありがとうございます。

このデータは RD-2000 の搭載機能を活かした以下の音色データを収録しています。

STONE : 31 個

収録内容

1. RD-EXP 05.bin

RD-2000 用のウェーブ・エクスパンション・データです。

2. RD-EXP 05_multi01_W.pdf

このファイルです。

3. RD-EXP 05_Readme_j.txt

テキスト版インストール方法です。

使用方法

1. ダウンロードしたファイル (RD-EXP 05.bin) を USB メモリーのルート (コンピューター上で見える一番上の階層) にコピーします。

2. USB メモリーを RD-2000 本体の背面にある MEMORY 端子に接続します。

3. [ENTER] ボタンを押しながら電源を入れます。

EXP Update Mode で RD-2000 が起動し、SLOT1/2 の状態を示す画面が表示されます。

4. 追加したい SLOT をカーソル・キーで選び、[ENTER] ボタンを押します。

USB メモリー上のファイル名 (RD-EXP 05.bin) が表示されます。

5. 追加したいファイル名を選んで、[ENTER] ボタンを押します。

6. 「Are you sure ?」が表示されたら、[ENTER] ボタンを押してデータ書き込みを実行します。

もしやり直したい場合は [EXIT] ボタンを押して、選択しなおしてください。

※ データ書き込み中は「Writing」の表示が出ています。データ書き込み時間は約 5 分です。「Complete」と表示が出たら完了です。

7. 電源を入れなおします。

[MENU] ボタンを押して SYSTEM-INFORMATION から Expansion のタイトルを確認することができます。

※ 万が一「Error」が表示されたり途中で中断されたりした場合は、上記の手順 1 番からやり直してください。

音色の選びかた

1. [EXP] ボタンを押します。

2. トーン・ナンバー (S01、0001 など) にカーソルを合わせて、バリュー・ダイヤルを回します。

著作権について

本データ、添付のドキュメントなどの著作権は、ローランド (株) が保有いたします。

免責

本音色データは、RD-2000 へのフォローアップ・サービスとして提供するものです。

本データを使用することによって生ずるいかなる損害についても、ローランド (株) はその責任を負いません。

Tone List

No.	TONE NAME	WHEEL TYPE	HARMONIC BARS	PERCUSSION	Rotary Type	Rotary Speed	Genre	Program Change
1	Fat Rock Organ	Vintage 2	88 8800 000	3RD, SOFT, FAST	Rotary Type2	SLOW	Rock	0
2	Earthy Jazz Org	Vintage 2	88 8000 000	3RD, SOFT, FAST	Rotary Type2	SLOW	Jazz/Funk	1
3	Gospel Main Org	Vintage 2	86 8888 332	OFF	Rotary Type2	FAST	Gospel	2
4	Crispy Funk Org	Vintage 2	88 8000 008	OFF	Rotary Type2	FAST	Funk	3
5	Wild Rock Organ	Vintage 2	88 8640 000	2ND, NORMAL, FAST	Rotary Type2	SLOW	Rock	4
6	Heavy Rock Organ	Vintage 2	88 8800 000	3RD, SOFT, SLOW	Rotary Type2	SLOW	Rock	5
7	Wide Spread Org	Vintage 2	88 8801 110	3RD, SOFT, FAST	Rotary Type2	SLOW	Rock	6
8	Clear Drive Org	Vintage 2	88 8800 000	3RD, SOFT, FAST	Rotary Type2	SLOW	Rock	7
9	Ballad Organ	Vintage 2	80 0000 888	OFF	Rotary Type2	FAST	Jazz	8
10	Light Jazz Organ	Vintage 2	00 8855 220	3RD, SOFT, SLOW	Rotary Type2	SLOW	Jazz	9
11	Clean Jazz Organ	Vintage 1	88 8000 000	3RD, SOFT, FAST	Rotary Type2	SLOW	Jazz	10
12	Gospel Intro Org	Vintage 2	00 8866 000	OFF	Rotary Type2	SLOW	Gospel	11
13	Hymn Organ	Vintage 1	30 8634 311	OFF	Rotary Type2	SLOW	Gospel	12
14	Funk Solo Organ	Vintage 2	88 8433 228	OFF	Rotary Type2	SLOW	Funk	13
15	Moody Organ	Vintage 2	00 8800 000	OFF	Rotary Type2	SLOW	Jazz/Gospel	14
16	Oldies Organ	Vintage 2	86 0000 068	OFF	Rotary Type2	SLOW	Pops	15
17	Full Bars	Vintage 2	88 8888 888	OFF	Rotary Type2	FAST	Any	16
18	Octave Combo	Vintage 2	80 8808 008	OFF	Rotary Type2	SLOW	Any	17
19	Non-octave Combo	Vintage 2	08 8080 880	OFF	Rotary Type2	SLOW	Any	18
20	Fast Transition	Vintage 2	88 8800 000	3RD, SOFT, FAST	Rotary Type2	SLOW	Any	19
21	Slow Transition	Vintage 2	88 8800 000	3RD, SOFT, FAST	Rotary Type2	SLOW	Any	20
22	Upper Organ 1	Vintage 2	88 8800 000	3RD, SOFT, FAST	Rotary Type2	SLOW	Any	21
23	Upper Organ 2	Vintage 2	88 8000 000	3RD, SOFT, FAST	Rotary Type2	SLOW	Any	22
24	Lower Organ	Vintage 2	00 8600 000	OFF	Rotary Type2	SLOW	Any	23
25	Manual Bass	Vintage 2	83 8000 000	OFF	Rotary Type2	SLOW	Any	24
26	Pedal Organ 16'	Vintage 2	88 7722 220	OFF	Rotary Type2	SLOW	Any	25
27	Pedal Organ 8'	Vintage 2	00 8888 450	OFF	Rotary Type2	SLOW	Any	26
28	TW-Organ V1	Vintage 1	88 8000 000	3RD, SOFT, FAST	Rotary	SLOW	Any	27
29	TW-Organ V2	Vintage 2	88 8000 000	3RD, SOFT, FAST	Rotary	SLOW	Any	28
30	TW-Organ V1 Rty2	Vintage 1	88 8000 000	3RD, SOFT, FAST	Rotary Type2	SLOW	Any	29
31	TW-Organ V2 Rty2	Vintage 2	88 8000 000	3RD, SOFT, FAST	Rotary Type2	SLOW	Any	30

MEMO

Turning the [TONE COLOR] knob changes the Rotary Speed (SLOW/FAST).

With the factory settings, you can also use Mod Wheel2 to operate TONE COLOR.

メモ

[TONE COLOR] つまみを回すと、Rotary Speed (SLOW/FAST) が変化します。

工場出荷時は Mod Wheel2 でも TONE COLOR を操作できます。