

EXZ001 “EXZ Stage Piano 1” Sound List／サウンド・リスト

Tone List

No.	Tone Name	Category	MSB	LSB	PC
1	Expressive Grand	Ac.Piano	101	64	1
2	Expressiv Bright	Ac.Piano	101	64	2
3	Expressive Warm	Ac.Piano	101	64	3
4	Expressive Mono	Ac.Piano	101	64	4
5	Expressive Grd 2	Ac.Piano	101	64	5
6	Expressive+EP 1	Ac.Piano	101	64	6
7	Expressive+EP 2	Ac.Piano	101	64	7
8	QuietPno+StrTrem	Ac.Piano	101	64	8
9	Expressive+Str	Ac.Piano	101	64	9
10	Expressive+Pad	Ac.Piano	101	64	10
11	Expressive+Bell	Ac.Piano	101	64	11

Waveform List

No.	Wave Name
1	ExpGrd mp AL
2	ExpGrd mp AR
3	ExpGrd mp BL
4	ExpGrd mp BR
5	ExpGrd mp CL
6	ExpGrd mp CR
7	ExpGrd mf AL
8	ExpGrd mf AR
9	ExpGrd mf BL
10	ExpGrd mf BR
11	ExpGrd mf CL
12	ExpGrd mf CR
13	ExpGrd f AL
14	ExpGrd f AR
15	ExpGrd f BL
16	ExpGrd f BR
17	ExpGrd f CL
18	ExpGrd f CR