

RD-EXP 02

RD-700SX Collection Vol.1

Read Me first

Thank you for downloading "RD-EXP 02: RD-700SX Collection Vol.1" for the RD-2000.
This data contains the following number of Sounds.
12 Tones

Contents

1. RD-EXP02.bin

This is the wave expansion data for the RD-2000.

2. RD-EXP02multi01_W.pdf

This is the file you're reading.

3. RD-EXP02_Readme_e.txt

This is a text version of the installation instructions.

Usage

1. Copy the downloaded file (RD-EXP02.bin) to the root directory of the USB memory.

2. Plug the USB memory into the MEMORY connector.

3. While pressing the [ENTER] button, turn on the power.

The EXP Update Mode will be activated and the screen will display the wave expansion data (e.g. RD-EXP02).

4. Use the cursor keys to select the slot into which you want to load the sounds, and press the [ENTER] button.

The name of the file on the USB flash drive (RD-EXP02.bin) appears.

5. Select the wave expansion data and press the [ENTER] button.

6. When the screen displays "Are you sure?" press the [ENTER] button to load the sounds.

If you would like to start over, press the [EXIT] button.

- * When the RD-2000 is loading the sounds, "Writing..." will be displayed on the screen. It will take approximately five minutes to load the sounds.
- When the RD-2000 is done loading the sounds, "Complete" will be displayed on the screen.

7. Reboot the RD-2000.

You can see the expansion titles by pressing the [MENU] button and checking SYSTEM-INFORMATION.

- * If for any reason RD-2000 stops loading the sounds or "Error" is displayed on the screen, please follow the instructions from the beginning.

Selecting Sounds

1. Press the [EXP] button.

2. Point the cursor to the BANK (e.g. S01, 0001), and then select EXP with the Value dial.

Copyright

Copyright to this data and the accompanying documentation is the property of Roland Corporation.

Disclaimers

This sound data is provided as after-sales service for the RD-2000.

Roland Corporation accepts no responsibility for any damages that may arise from the use of this data.

はじめにお読みください

このたびは、RD-2000用「RD-EXP 02:RD-700SX Collection Vol.1」データをダウンロードしていただき、誠にありがとうございます。
このデータはRD-2000の搭載機能を活かした以下の音色データを収録しています。
TONE:12個

収録内容

1. RD-EXP02.bin
RD-2000用のウェーブ・エクスパンション・データです。
2. RD-EXP02multi01_W.pdf
このファイルです。
3. RD-EXP02_Readme_j.txt
テキスト版インストール方法です。

使用方法

1. ダウンロードしたファイル (RD-EXP02.bin) をUSBメモリーのルート (コンピューター上で見える一番上の階層) にコピーします。
2. USBメモリーをRD-2000本体の背面にあるMEMORY端子に接続します。
3. [ENTER] ボタンを押しながら電源を入れます。
EXP Update ModeでRD-2000が起動し、SLOT1/2の状態を示す画面が表示されます。
4. 追加したいSLOTをカーソル・キーで選び、[ENTER] ボタンを押します。
USBメモリー上のファイル名 (RD-EXP02.bin) が表示されます。
5. 追加したいファイル名を選んで、[ENTER] ボタンを押します。
6. 「Are you sure?」が表示されたら、[ENTER] ボタンを押してデータ書き込みを実行します。
もしやり直したい場合は[EXIT]ボタンを押して、選択しなおしてください。
※ データ書き込み中は「Writing」の表示が出ています。データ書き込み時間は約5分です。「Complete」と表示が出たら完了です。
7. 電源を入れなおします。
[MENU] ボタンを押してSYSTEM-INFORMATIONからExpansionのタイトルを確認することができます。
※ 万が一「Error」が表示されたり途中で中断されたりした場合は、上記の手順1番からやり直してください。

音色の選びかた

1. [EXP] ボタンを押します。
2. トーン・ナンバー(S01、0001など)にカーソルを合わせて、バリュー・ダイヤルを回します。

著作権について

本データ、添付のドキュメントなどの著作権は、ローランド (株) が保有いたします。

免責

本音色データは、RD-2000へのフォローアップ・サービスとして提供するものです。
本データを使用することによって生ずるいかなる損害についても、ローランド (株) はその責任を負いません。

Tone List

No.	Name	Program Change
1	7SX Superior Grd	0
2	7SX Dark Ballad	1
3	7SX Bright Grand	2
4	7SX Superior Str	3
5	7SX Superior Pd1	4
6	7SX Superior Pd2	5
7	7SX Hybrid Grd 1	6
8	7SX Hybrid Grd 2	7
9	7SX Dynamic Grd	8
10	7SX Rock Piano 1	9
11	7SX Honky-tonk	10
12	7SX SuperiorMono	11

MEMO

Although the sounds of the RD-700SX are faithfully reproduced, the keyboard is more expressive on the RD-2000. If you want to perform with a touch response that is closer to that of the RD-700SX, set KEY TOUCH to a lighter setting.

メモ

RD-700SXの音色を忠実に再現しておりますが、RD-2000では鍵盤の表現力が向上しています。RD-700SXに、より近いタッチで演奏するには、KEY TOUCHを軽めに設定するとよいでしょう。